



**TS-140 TS-440 TS-450 TS-680 TS-690 TS-711 TS-790 TS-811 TS-850 TS-940 TS-950**

**Notes:**

\* **FSK RCA is necessary only for the TS-850 TS-950**

TS50 , TS60 - requires Kenwood IF-10D  
 TS140 , TS680 - requires Kenwood IF-10C  
 TS711 , TS811 - requires Kenwood IF-10A  
 TS 940 - requires Kenwood IF-10B  
 TS 440 - requires Kenwood IC-10